



THALESNano



## Manual Inlet Valve Switch for H-Cube®

The manual inlet valve switch allows the user to change the flow into the H-Cube® between solvent and substrate without the need to physically transfer the inlet line.

Using the Manual Inlet Valve Switch allows for a more convenient use of the H-Cube®, with less likelihood of spillage or of air being drawn into the pump.

The manual inlet valve can be fitted to any H-Cube® in a matter of minutes and is available as a standard 2-line inlet valve, or with a 6-line valve changer for multiple sample and solvent combinations.

For prices and further information contact:

**ThalesNano Inc.**  
Záhony u. 7.  
H-1031 Budapest, Hungary  
Tel: (36 1) 880 8500  
Fax: (36 1) 880 8501

**Thales LLC,**  
Princeton, NJ, USA  
Tel: (1) 732 274 3388

E-mail: [info@thalesnano.com](mailto:info@thalesnano.com)  
[www.thalesnano.com](http://www.thalesnano.com)

